



(1) POWER BUTTON

PRIMARY FUNCTIONS = Unit ON/OFF & Phone Activation

SECONDARY FUNCTIONS = Bluetooth Pairing & Unit Intercom Pairing

(2) VOLUME UP BUTTON

PRIMARY FUNCTION = Unit Volume Up

SECONDARY FUNCTION = Voice Activation Level Increase

(3) VOLUME DOWN BUTTON

PRIMARY FUNCTION = Unit Volume Down

SECONDARY FUNCTION = Voice Activation Level Decrease

(4) MODE BUTTON

PRIMARY FUNCTION = Switch Between Intercom & Broadcast Audio

SECONDARY FUNCTION = Unit Intercom Pairing

(5) PTT BUTTON

PRIMARY FUNCTION = Push To Talk For Intercom Communication

SECONDARY FUNCTION = Activate/Deactivate Voice Activation
For Intercom Communication

(6) CHARGE INPUT PORT

PRIMARY FUNCTION = Charge Cord Input Port

SECONDARY FUNCTION = Optional Auxiliary Audio Cord Input Port

(7) HEADSET INPUT PORT

PRIMARY FUNCTION = Headset Cord Input Port

SECONDARY FUNCTION = None

(8) LED

PRIMARY FUNCTION (RED) = Unit On/Off & Intercom Pairing Status

SECONDARY FUNCTION (BLUE) = Bluetooth & Charging Status

BASIC UNIT OPERATION

CHARGE XBi UNIT BEFORE PERFORMING ANY OPERATIONS

READ THROUGH INSTRUCTIONS COMPLETELY BEFORE ATTEMPTING OPERATION

CHARGING XBi UNIT

- 1 **XBi** unit must be off
- 2 Plug charger into 110 volt household power supply
- 3 Plug charge cord into Charge Input Port **(6)**
- 4 LED **(8)** will light steady BLUE and remain on for entire charging cycle
- 5 BLUE LED **(8)** will turn off once charging cycle is complete (approx 1 hr)
- 6 Unplug charge cord from Charge Input Port **(6)**

TURNING XBi UNIT ON

- 1 Press and hold Power Button **(1)** until LED **(8)** lights steady RED
- 2 Release Power Button **(1)**
- 3 LED **(8)** will now alternate flashing BLUE & flashing RED continuously

TURNING XBi UNIT OFF

- 1 Press and hold Power Button **(1)** until LED **(8)** lights steady RED
- 2 A two-tone sound will be heard (BEEP-BOOP)
- 3 Release Power Button **(1)**
- 4 LED **(8)** will now be off

ADJUSTING XBi UNIT VOLUME

- 1 **XBi** unit will be at middle volume level whenever unit is turned on
- 2 Momentarily press (approximately 1 second) the desired volume button
- 3 At maximum or minimum volume level a single-tone sound will be heard (BOOP)

BLUETOOTH OPERATION

CHARGE XBi UNIT BEFORE PERFORMING ANY OPERATIONS

READ THROUGH INSTRUCTIONS COMPLETELY BEFORE ATTEMPTING OPERATION

PUTTING UNIT INTO BLUETOOTH PAIRING MODE

- 1 Start with **XBi** unit off
- 2 Press and hold Power Button **(1)**
- 3 LED **(8)** will light steady RED then after approximately six seconds start flashing BLUE
- 5 Release Power Button **(1)**
- 6 **XBi** unit is now in Bluetooth pairing mode
- 7 Complete device pairing

PAIRING A BLUETOOTH COMPATIBLE PHONE

- 1 Prepare **Phone** to search for Bluetooth devices
- 2 Put **XBi** unit in Bluetooth pairing mode (see above)
- 3 Press search button on **Phone**
- 4 Select “XBi” from **Phone** device list
- 5 Enter pass code in **Phone** (pass code will always be “0000”)
- 6 Press connect to “XBi” on **Phone**
- 7 **XBi** unit is now paired with **Phone** and will only need to be connected when **XBi** unit is turned on

PAIRING A STEREO BLUETOOTH AUDIO SOURCE ADAPTOR

- 1 Turn on audio source and prepare **Stereo Bluetooth Adaptor** for pairing
- 2 Put **XBi** unit in Bluetooth pairing mode (see above)
- 3 Turn on or plug in **Stereo Bluetooth Adaptor**
- 4 Audio source will automatically start playing though **XBi** unit when pairing is complete
- 7 **XBi** unit is now paired with **Stereo Bluetooth Adaptor** and will only need to be plugged in or turned on when **XBi** unit is turned on

AUDIO SOURCES WITH BUILT IN BLUETOOTH WILL PAIR SIMILAR TO PHONES

**FOR PAIRING ISSUES OR DEVICES NOT COVERED BY THE INSTRUCTIONS
PLEASE CALL CHATTERBOX! @ (888) 452-2269 FOR TECHNICAL ASSISTANCE**

ALWAYS CONNECT STEREO AUDIO SOURCE TO XBi BEFORE CONNECTING PHONE

CONNECTING A PAIRED BLUETOOTH PHONE VIA THE PHONE

- 1 Turn *XBi* unit on
- 2 Highlight “XBi” on *Phone* Bluetooth device list
- 3 Press connect to “XBi” on *Phone*
- 4 Bluetooth symbol will light on *Phone* display

CONNECTING A PAIRED BLUETOOTH PHONE VIA THE XBi UNIT

WHEN USING THIS PROCEDURE

**SOME PHONES WILL TRY TO DIAL THE LAST NUMBER DIALED ONCE CONNECTED
BE PREPARED TO PRESS THE END CALL BUTTON ON YOUR PHONE**

- 1 Turn *XBi* unit on
- 2 Momentarily press (approximately 1 second) the Power Button (1)
- 3 Bluetooth symbol will light up on *Phone* display
- 4 Press end call button on *Phone*

ANSWERING A CALL VIA THE XBi UNIT

INTERCOM COMMUNICATION IS UNAVAILABLE DURING PHONE USE

- 1 When a call is received a three-tone sound will be heard (DUNG-DUNG-DUNG)
- 2 Stereo audio source and/or intercom communication is muted
- 3 Momentarily press (approximately 1 second) the Power Button (1) to answer call
- 4 Conduct phone call
- 5 Momentarily press (approximately 1 second) the Power Button (1) to end call
- 6 Stereo audio source and/or intercom communication will be restored

PLACING A CALL VIA THE XBi UNIT

INTERCOM COMMUNICATION IS UNAVAILABLE DURING PHONE USE

- 1 Dial desired number on *Phone* keypad
- 2 Momentarily press (approximately 1 second) the Power Button (1) to initiate call
- 3 Stereo audio source and/or intercom communication is muted
- 4 Conduct phone call
- 5 Momentarily press (approximately 1 second) the Power Button (1) to end call
- 6 Stereo audio source and/or intercom communication will be restored

**FOR CONNECTION OR FUNCTION ISSUES NOT COVERED BY THE INSTRUCTIONS
PLEASE CALL CHATTERBOX! @ (888) 452-2269 FOR TECHNICAL ASSISTANCE**

INTERCOM OPERATION

CHARGE XBi UNITS BEFORE PERFORMING ANY OPERATIONS

READ THROUGH INSTRUCTIONS COMPLETELY BEFORE ATTEMPTING OPERATION

RIDER (MASTER) & PASSENGER (SLAVE) UNIT ASSIGNMENT

TWO XBi UNITS ARE NECESSARY FOR WIRELESS INTERCOM FUNCTION

LABEL OR MARK XBi UNITS FOR FUTURE IDENTIFICATION

- 1 Start with both *XBi* units off
- 2 Turn on *Rider (Master) XBi* unit
- 3 Press & hold both Power Button (1) and Mode Button (4) simultaneously
- 4 LED (8) will start to flash RED once every second then speed up to twice every second
- 5 Release both Power Button (1) and Mode Button (4) simultaneously
- 6 Turn on *Passenger (Slave) XBi* unit
- 7 Press & hold both Power Button (1) and Mode Button (4) simultaneously
- 8 LED (8) will start to flash RED once every second
- 9 Release both Power Button (1) and Mode Button (4) simultaneously
- 10 Turn both *XBi* units off
- 11 *XBi* units are now paired and will connect to each other automatically when both *XBi* units are on and within range of each other

VOICE ACTIVATED INTERCOM COMMUNICATION

TWO XBi UNITS ARE NECESSARY FOR WIRELESS INTERCOM FUNCTION

XBi UNITS ARE AUTOMATICALLY IN VOICE-ACTIVATED MODE WHEN TURNED ON

INTERCOM COMMUNICATION IS UNAVAILABLE DURING PHONE USE

- 1 Turn on *Rider (Master) & Passenger (Slave) XBi* units
- 2 *XBi* units will automatically be in voice-activated mode whenever they are turned on
- 3 *XBi* units will automatically connect to each other when previously paired as above
- 4 Speak into microphone to activate intercom communication
- 5 Stereo audio sources will be muted during intercom communication
- 6 Intercom communication will deactivate when speaking stops or pauses
- 7 If *XBi* unit self activates or will not deactivate because of ambient noise (wind, motor, etc.) adjust voice-activated sensitivity level per instructions below
- 8 Stereo audio sources will be restored when intercom communication is deactivated

ADJUSTING VOICE ACTIVATED SENSITIVITY

XBi UNITS ARE AUTOMATICALLY IN VOICE-ACTIVATED MODE WHEN TURNED ON

THERE ARE 5 SENSITIVITY LEVEL STEPS

XBi UNITS RETAIN LAST SENSITIVITY SETTING WHEN TURNED OFF/ON

DECREASE VOICE-ACTIVATED SENSITIVITY

- 1 Press and hold (approximately 3 seconds) Volume Down Button **(3)**
- 2 A single-tone sound will be heard (BOOP)
- 3 Release Volume Down Button **(3)**
- 4 At minimum sensitivity a two-tone sound will be heard (BEEP-BOOP)

INCREASE VOICE-ACTIVATED SENSITIVITY

- 1 Press and hold (approximately 3 seconds) Volume Up Button **(2)**
- 2 A single-tone sound will be heard (BOOP)
- 3 Release Volume Up Button **(2)**
- 4 At maximum sensitivity a two-tone sound will be heard (BEEP-BOOP)

DEACTIVATING VOICE ACTIVATED MODE

XBi UNITS ARE AUTOMATICALLY IN VOICE-ACTIVATED MODE WHEN TURNED ON

- 1 Momentarily press (approximately 1 second) the PTT Button **(5)**
- 2 A four-tone sound will be heard (BEEP-BEEP-BEEP-BEEP)
- 3 Intercom communication will now only be available via the PTT Button **(5)**

PUSH TO TALK (PTT) INTERCOM COMMUNICATION

XBi UNITS ARE AUTOMATICALLY IN VOICE-ACTIVATED MODE WHEN TURNED ON

PTT FUNCTION OPERATES IN VOICE-ACTIVATED MODE ALSO

INTERCOM COMMUNICATION IS UNAVAILABLE DURING PHONE USE

- 1 Press and hold PTT Button **(5)**
- 2 Stereo audio sources will be muted during intercom communication
- 3 Conduct intercom communication
- 4 Release PTT Button **(5)**
- 5 Stereo audio sources will be restored when intercom communication is deactivated

REACTIVATING VOICE ACTIVATED MODE

XBi UNITS ARE AUTOMATICALLY IN VOICE-ACTIVATED MODE WHEN TURNED ON

XBi UNITS RETAIN LAST SENSITIVITY SETTING WHEN TURNED OFF/ON

PTT FUNCTION OPERATES IN VOICE-ACTIVATED MODE ALSO

INTERCOM COMMUNICATION IS UNAVAILABLE DURING PHONE USE

- 1 Momentarily press (approximately 1 second) the PTT Button **(5)**
- 2 A two-tone sound will be heard (BOOP-BEEP)
- 3 Intercom communication will now be available via voice activated mode

BROADCASTING STEREO AUDIO SOURCE

**INTERCOM COMMUNICATION IS UNAVAILABLE DURING
STEREO AUDIO BROADCASTING**

STEREO AUDIO BROADCASTING IS UNAVAILABLE DURING PHONE USE

BROADCAST CAN BE FROM EITHER XBi UNIT

- 1 Connect stereo audio source to either *XBi* unit per instructions
- 2 Press and hold (approximately 4 seconds) Mode Button **(4)**
- 3 A three-tone sound will be heard (BEEP-BEEP-BOOP)
- 4 Release Mode Button **(4)**
- 5 Stereo audio source should now be heard in both *XBi* units